

# UNIDEN PROGRAMMING CONTROL CODES FOR USE WITH UNIDEN SCANNERS

## *End User License Agreement* UNIDEN AMERICA CORPORATION

**NOTICE TO USER:** THIS END USER LICENSE AGREEMENT ("EULA") IS A LEGAL AGREEMENT BETWEEN YOU AND UNIDEN. PLEASE READ THIS CAREFULLY BEFORE USING THE UNIDEN CODE. BY CLICKING THE "I AGREE TO THE TERMS OF THIS LICENSE AGREEMENT", OR BY USING ALL OR ANY PORTION OF THE UNIDEN CODE, YOU ARE CONFIRMING YOUR ACCEPTANCE OF THE UNIDEN CODE AND ALL THE TERMS AND CONDITIONS OF THIS AGREEMENT. IF YOU DO NOT AGREE, DO NOT USE THE UNIDEN CODE. CLICK THE "I DO NOT AGREE TO THE TERMS OF THIS LICENSE AGREEMENT" FOR THE INSTALLATION PROCESS TO TERMINATE.

### **1. DEFINITIONS**

- (A) "Uniden Code" means Uniden proprietary programming codes and commands used to control Uniden's scanner products.
- (B) "Use" or "Using" means to access, install, download, copy or otherwise benefit from using the functionality of the Uniden Code.
- (C) "Computer" means an electronic device that accepts information in digital or similar form and manipulates it for a specific result based on a sequence of instructions.
- (D) "Uniden" means Uniden America Corporation, a Delaware corporation, located at 4700 Amon Carter Boulevard, Fort Worth, Texas 76155, and its licensors, if any.

### **2. UNIDEN CODE LICENSE GRANTS**

- (A) You may utilize the Uniden Code on an "as is", at-will, royalty-free, personal, non-assignable, non-exclusive basis solely for the purpose of creating software or firmware products intended to extend the functionality of Uniden scanner products, or provide compatibility of Uniden scanner products with a PC or other control devices.
- (B) You agree that the Uniden Code will not be used to create a competing scanner product.

- (C) You agree not to use the Uniden Code functionality for purposes other than to control one or more of the Uniden scanner models to which the codes apply.
- (D) You acknowledge that the Uniden Code is provided "as-is" and that Uniden has no obligation to provide any additional support in the use of the Uniden Code beyond the disclosed documentation.
- (E) User acknowledges that, while reasonable efforts have been taken to ensure accuracy in the supplied documentation, said documents have been subjected to one or more translation stages that might have resulted in unclear, inaccurate, or incomplete information and that Uniden is under no obligation to correct or clarify supplied documentation of the Uniden Code.
- (F) You acknowledge that the Uniden Code is the sole property of Uniden.
- (G) You agree that the Uniden Code, documentation thereof and the related information provided by Uniden are confidential and proprietary information of Uniden (collectively "Uniden Confidential Information").
- (H) You agree to mark any software containing all or part of the Uniden Code, and the written user materials accompanying units that incorporate Uniden Code with notices indicating, "This product contains Uniden proprietary and/or copyright control codes. Used with permission."
- (I) You agree that this EULA does not need to be signed for it to take effect.
- (J) You agree to use the Uniden Code in its regular and proper manner.
- (K) You acknowledge that Uniden may update, modify or revise the Uniden Code at any time and shall not be obligated to provide such updates, modifications or revisions to you.
- (L) You acknowledge that the permission granted herein does not constitute endorsement by Uniden of any software or firmware products you may create in accordance with the purpose stated in section A herein; and you are solely responsible for the configuration of said software or firmware and/or any service matters relating to said software or firmware and/or any Uniden Code used with said software or firmware.
- (M) This license is personal to you and you may make copies of the Uniden Code only for your personal use.

- (N) You agree that Uniden may audit your use of the Uniden Code for compliance with these terms at any time.
- (O) You agree and represent that any products you create which incorporate the Uniden Code are in compliance with all applicable laws.
- (P) You shall defend, indemnify and hold harmless Uniden, its subsidiaries and affiliates, and all agents, employees, officers and directors of Uniden, its subsidiaries and affiliates, from all expenses, losses, costs, damages or liability (including reasonable attorneys' fees and court costs and expenses) arising out of or in connection with any claim or action in connection with the use of any products you create which incorporate the Uniden Code.

### **3. LICENSE RESTRICTIONS**

- (A) Other than as set forth in Section 2 of this EULA, you may not make or distribute copies of the Uniden Code, or electronically transfer the Uniden Code from one computer to another or over a network.
- (B) You may not alter, merge, modify, adapt or translate the Uniden Code, or decompile, reverse engineer, disassemble, or otherwise reduce the Uniden Code to a human-perceivable form.
- (C) You may not sell, rent, lease, assign or sublicense the Uniden Code.
- (D) You may not modify the Uniden Code or create derivative works based upon the Uniden Code.
- (E) You may not export the Uniden Code into any country prohibited by the United States Export Administration Act and the regulations thereunder.
- (F) In the event that you fail to comply with this EULA, Uniden may terminate the license and you must destroy all copies of the Uniden Code (with all other rights of both parties and all other provisions of this EULA surviving any such termination).

### **4. OWNERSHIP**

The foregoing license gives you limited license to use the Uniden Code. Uniden retains all right, title and interest, including all copyright and intellectual property rights, in and to, the Uniden Code or any derivative works, including but not limited to the structure and organization of the Uniden Code, and all copies thereof. All rights not specifically granted in this EULA, including Federal and

International Copyrights, are reserved by Uniden. Uniden reserves the right to terminate this license at any time.

## **5. WARRANTY DISCLAIMER**

- (A) THE UNIDEN CODE IS PROVIDED TO YOU ON AN "AS-IS" BASIS. UNIDEN PROVIDES NO TECHNICAL SUPPORT OR WARRANTIES FOR THE UNIDEN CODE.
- (B) UNIDEN AND ITS SUPPLIERS DISCLAIM ALL WARRANTIES AND REPRESENTATIONS (EXPRESS OR IMPLIED WHETHER BY STATUTE, COMMON LAW, CUSTOM, USAGE OR OTHERWISE) INCLUDING THE WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE. ALSO, THERE IS NO WARRANTY OF SATISFACTORY QUALITY, INTEGRATION, NON-INFRINGEMENT OF THIRD PARTY RIGHTS AND TITLE OR QUIET ENJOYMENT. UNIDEN DOES NOT WARRANT THAT THE UNIDEN CODE IS ERROR-FREE OR WILL OPERATE WITHOUT INTERRUPTION. NO RIGHTS OR REMEDIES REFERRED TO IN ARTICLE 2A OF THE UCC WILL BE CONFERRED ON YOU UNLESS EXPRESSLY GRANTED HEREIN.
- (C) IF APPLICABLE LAW REQUIRES ANY WARRANTIES WITH RESPECT TO THE UNIDEN CODE, ALL SUCH WARRANTIES ARE LIMITED IN DURATION TO THIRTY (30) DAYS FROM THE DATE OF DELIVERY.
- (D) NO ORAL OR WRITTEN INFORMATION OR ADVICE GIVEN BY UNIDEN, ITS DEALERS, SUPPLIERS, DISTRIBUTORS, AGENTS OR EMPLOYEES SHALL CREATE A WARRANTY OR IN ANY WAY INCREASE THE SCOPE OF ANY WARRANTY PROVIDED HEREIN.

## **6. LIMITATION OF LIABILITY**

- (A) NEITHER UNIDEN NOR ITS SUPPLIERS SHALL BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, COVER OR CONSEQUENTIAL DAMAGES (INCLUDING, BUT NOT LIMITED TO, DAMAGES FOR THE INABILITY TO USE EQUIPMENT OR ACCESS DATA, LOSS OF BUSINESS, LOSS OF PROFITS, BUSINESS INTERRUPTION OR THE LIKE), ARISING OUT OF THE USE OF, OR INABILITY TO USE, THE UNIDEN CODE AND BASED ON ANY THEORY OF LIABILITY INCLUDING BREACH OF CONTRACT, BREACH OF WARRANTY, TORT (INCLUDING NEGLIGENCE), PRODUCT LIABILITY OR OTHERWISE, EVEN IF UNIDEN OR ITS REPRESENTATIVES HAVE BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES AND EVEN IF A REMEDY SET

FORTH HEREIN IS FOUND TO HAVE FAILED OF ITS ESSENTIAL PURPOSE.

- (B) UNIDEN'S TOTAL LIABILITY TO YOU FOR ACTUAL DAMAGES FOR ANY CAUSE WHATSOEVER WILL BE LIMITED TO THE GREATER OF \$10 OR THE AMOUNT PAID BY YOU FOR THE UNIDEN CODE THAT CAUSED SUCH DAMAGE.
- (C) THE FOREGOING LIMITATIONS ON LIABILITY ARE INTENDED TO APPLY TO THE WARRANTIES AND DISCLAIMERS ABOVE AND ALL OTHER ASPECTS OF THIS EULA.

## **7. COMPLIANCE WITH LAWS**

Uniden and its affiliates, which offer the Uniden Code to you, are headquartered in the United States. Uniden makes no representation that the Uniden Code is appropriate or legal for use inside or outside the United States. You are responsible for all compliance with your local laws, and use of the Uniden Code where illegal is expressly prohibited.

## **8. GOVERNING LAW AND VENUE**

This EULA shall be interpreted, construed and governed by the laws of the State of Texas, USA, without reference to its laws relating to conflicts of law and not including the provisions of the 1980 United Nations Convention on Contracts for the International Sale of Goods. Venue for all disputes arising under this Agreement shall lie exclusively in the District Courts of the State of Texas in Tarrant County or the Federal District Courts of the Northern District of Texas (as permitted by law) and each party agrees not to contest the personal jurisdiction of these courts. Notwithstanding the foregoing, however, Uniden shall have the right to commence and prosecute any legal or equitable action or proceeding before any non-US court of competent jurisdiction to obtain injunctive or other relief in the event that, in the opinion of Uniden, such action is necessary or desirable.

## **9. GENERAL PROVISIONS.**

This EULA contains the complete agreement between the parties with respect to the subject matter hereof, and supersedes all prior or contemporaneous agreements or understandings, whether oral or written. You agree that any varying or additional terms contained in any purchase order or other written notification or document issued by you in relation to the Uniden Code licensed hereunder shall be of no effect. The failure or delay of Uniden to exercise any of its rights under this EULA or upon any breach of this EULA shall not be deemed a waiver of those rights or of the breach.

If any provision of this EULA shall be held by a court of competent jurisdiction to be contrary to law, that provision will be enforced to the maximum extent permissible, and the remaining provisions of this EULA will remain in full force and effect.

All questions concerning this EULA shall be directed to: Uniden America Corporation, 4700 Amon Carter Boulevard, Fort Worth, Texas 76155.

UNIDEN and other trademarks contained in the Uniden Code are trademarks or registered trademarks of Uniden America Corporation in the United States and/or other countries. You may not remove or alter any trademark, trade names, product names, logo, copyright or other proprietary notices, legends, symbols or labels in the Uniden Code. This EULA does not authorize you to use the UNIDEN name or any of their respective trademarks.

Trademarks and registered trademarks:

All products or service names mentioned in the Uniden Code are trademarks or registered trademarks of Uniden America Corporation.

Copyright © 2003-2004

Uniden America Corporation  
ALL RIGHTS RESERVED

## REMOTE COMMAND

Version: 1.05

### Remote Communication Format

BPS Rate	: 2400/4800/9600/19200/38400/57600 bps
Start/Stop bit	: 1 bit, 1 bit
Data Length	: 8 bit
Parity Check	: None
Code	: ASCII
Flow Control	: None
Return Code	: Carriage Return only

**Note:**

- 1) In case of controlling with program, insert waiting time between commands.
- 2) On Menu mode, only KEY emulation commands is valid.
- 3) The command to change the scanner setting may change a setup item except for the applicable setup item, too.

Most of these commands depend on the specifications of your Scanner.

Ex) "PM" command or "PR" command

## FORMAT OF THIS DOCUMENT

---

---

**COMMAND NAME** : Summary explanation of the function of the command

---

---

Controller → Radio

Command format

Radio → Controller

Response format

※ Error message isn't described in this document,  
but the unit sends error message to the controller as follows.

- 1)Command format error / Value error : ERR[¥r]
- 2)The command is invalid at the time : NG[¥r]
- 3)Flaming error : FER[¥r]
- 4)Overrun error : ORER[¥r]

< BCT8 OPERATION SPECIFICATION >

※ [¥r] means "to hit the Enter key" or "to send the Return code".

※ The channel bank or search No. assign to alphabet.

Ex) BANK1 :A BANK2 :B ---- BANK5 :E

※ The ID list No. assign to alphabet.

Ex) LIST1 :A LIST2 :B ---- LIST5 :E

Command List

		Command Name	Page
1	<b>AC</b>	: Clear (Initialize) all memory	4
2	<b>AF</b>	: Confirm/Set EDACS AFS ID Format	4
3	<b>BC</b>	: Confirm Base, Space, Offset Configuration	5
4	<b>BC</b>	: Confirm Base, Space, Offset Configuration	5
5	<b>BT</b>	: Confirm/Set S-BIT function	6
6	<b>DL</b>	: Confirm/Set DELAY function	6
7	<b>DS</b>	: Confirm/Set DATA SKIP function	7
8	<b>EL</b>	: Confirm/Set Enter Lock feature	7
9	<b>FB</b>	: Confirm/Program fleet block	8
10	<b>FI</b>	: Confirm/Set Frequency Identification function	8
11	<b>HA</b>	: informs when highway alert condition changes.	9
12	<b>HP</b>	: informs when highway alert signal receive.	9
13	<b>HW</b>	: Confirm/Set Highway scan mode	10
14	<b>IC</b>	: Confirm/Move/Program Talk Group ID Location No.	10
15	<b>ID</b>	: informs when ID reception starts or ends	14
16	<b>IL</b>	: Read / Register / Delete L/O ID memory	17
17	<b>IS</b>	: Confirm/Select ID scan lists.	22
18	<b>KEY</b>	: KEY emulation command	23
19	<b>LCD</b>	: Read LCD	24
20	<b>LO</b>	: Confirm/Set LOCKOUT Channel	25
21	<b>MA</b>	: Confirm / Move the channel No.	26
22	<b>MD</b>	: Confirm the Scanner mode	27
23	<b>MU</b>	: Confirm/Set status of speaker muting.	28
24	<b>PC</b>	: Confirm/Set priority channel No. of a bank.	28
25	<b>PI</b>	: Confirm/Set Priority Talk ID Memory Location	29
26	<b>PM</b>	: Read / Program a channel frequency	30
27	<b>PR</b>	: Confirm/Set PRIORITY function	31
28	<b>QU</b>	: informs when squelch condition changes	31
29	<b>RF</b>	: Confirm/Tune the commanded frequency	32
30	<b>RG</b>	: Confirm /Set EDACS ID Range mode.	33
31	<b>RI</b>	: informs when priority receiving condition changes	33
32	<b>RM</b>	: Confirm receive mode	34
33	<b>SB</b>	: Confirm/Select scan banks	34
34	<b>SI</b>	: Confirm Scanner Information	35
35	<b>SQ</b>	: Confirm squelch condition	35
36	<b>SS</b>	: Read / Register a frequency in search skip memory	36
37	<b>ST</b>	: Confirm frequency step	37
38	<b>SV</b>	: Confirm/Set Service scan mode	37
39	<b>TB</b>	: Confirm/Set Trunking bank On/Off	38
40	<b>TC</b>	: Confirm/Set Control channel only mode	39
41	<b>TD</b>	: Confirm/Set Motorola disconnect Tone option	40
42	<b>TG</b>	: Program Talk Group ID	40
43	<b>TR</b>	: Set trunking to bank	45
44	<b>US</b>	: Confirm/Select U.S state	46
45	<b>VR</b>	: Confirm the version of the Product	47
46	<b>WD</b>	: Confirm/Set Warning light Dimmer	47
47	<b>WL</b>	: Confirm warning light status	48
48	<b>WM</b>	: Confirm warning mute condition	48

=====

**AC** : Clear (Initialize) all memory

=====

Controller → Radio

AC[¥r]

Radio → Controller

OK[¥r]

This command instructs the unit to clear all the memories.

All the memories are set for initial setting

This command is valid at any time.

Note) There needs about 3seconds execute time.

Start from highway scanning(state AK) by initial setting.

=====

**AF** : Confirm/Set EDACS AFS ID Format

=====

Controller → Radio

- ① AF[¥r] : Confirm AFS ID Form mode ON/OFF
- ② AFN[¥r] : AFS ID Form mode ON
- AFF[¥r] : AFS ID Form mode OFF

Radio → Controller

- ① AFN[¥r] : AFS ID Form mode ON
- AFF[¥r] : AFS ID Form mode OFF
- ② OK[¥r]

This command instructs the unit to turn or confirm AFS ID function ON/OFF.

Note:

If you ass the Bank No.(A-E) at the end, you can select optional bank.

Ex) "AF A" or "AFN A"

=====

**AV** : Confirm/Set alert volume

=====

Controller → Radio

- ① AV[¥r] : Confirm alert volume setting
- ② AV@[¥r] : Set alert volume without alert sound
  - @ : volume level
    - H: high level sound
    - M: middle level sound
    - L: low level sound

Note:

if you add the "?" at the end , you can hear the alert sound.

Ex) AV? Or AVH?

Radio → Controller

- ① AV@[¥r] : Set alert volume
  - @ : volume level
    - H: high level sound
    - M: middle level sound
    - L: low level sound
- ② OK[¥r]

=====

**BC** : Confirm Base, Space, Offset Configuration

=====

Controller → Radio

BC @#[¥r]

- @ : Bank No.(A-E)
- # : Configuration No. (1,2,3)

Radio → Controller

BC @# %%%%%%%% \$\$\$ XXX[¥r]

- @ : Bank No.(A-E)
- # : Configuration No. (1,2,3)

%%%%%%% : Base frequency

\$\$\$ : Space frequency

(multiple of 5.0kHz : 0050,0100, 0150,,,, 1000 )

< BCT8 OPERATION SPECIFICATION >

(multiple of 12.5kHz: 0125,0250,0375 ,,,, 1000 )  
XXX : Offset channel (380 - 759 )

Example)

BC C1 01380000 0500 0380[¥r]

Bank No. : 3  
Configuration No : 1  
Base Frequency : 138.0000MHz  
Space frequency : 50kHz  
Offset channel : 380

=====

**BT** : Confirm/Set S-BIT function

=====

Controller → Radio

① BT[¥r] : Confirm S-BIT function ON/OFF  
② BTN[¥r] : S-BIT ON  
BTF[¥r] : S-BIT OFF

Radio → Controller

① BTN[¥r] : S-BIT ON  
BTF[¥r] : S-BIT OFF  
② OK[¥r]

Note:

if you add the bank No(A-E) at the end , you can select your optional bank.

Ex) "BT A" Or "BTN A"

This command instructs the unit to turn or confirm S-BIT function ON/OFF.

=====

**DL** : Confirm/Set DELAY function

=====

Controller → Radio

① DL[¥r] : Confirm DELAY function ON/OFF  
② DLN[¥r] : 2seconds delay ON  
DLF[¥r] : Delay OFF

Radio → Controller

- ① DLN[¥r] : Delay ON
- DLF[¥r] : Delay OFF
- ② OK[¥r]

This command instructs the unit to turn or confirm DELAY function ON/OFF.

=====

**DS** : Confirm/Set DATA SKIP function

=====

Controller → Radio

- ① DS[¥r] : Confirm DATA SKIP function ON/OFF
- ② DSN[¥r] : Data skip ON
- DSF[¥r] : Data skip OFF

Radio → Controller

- ① DSN[¥r] : Data skip ON
- DSF[¥r] : Data skip OFF
- ② OK[¥r]

This command instructs the unit to turn or confirm DATA SKIP function ON/OFF.

=====

**EL** : Confirm/Set Enter Lock feature

=====

Controller → Radio

- ① EL[¥r] : Confirm ENTER LOCK ON/OFF
- ② ELN[¥r] : Set ENTER LOCK to ON
- ELF[¥r] : Set ENTER LOCK to OFF

Radio → Controller

- ① ELN[¥r] : ENTER LOCK is ON
- ELF[¥r] : ENTER LOCK is OFF
- ② OK[¥r] : Command OK

=====

**FB** : Confirm/Program fleet block

=====

Controller → Radio

- ① **FB & #[\$r]** : Confirm Fleet Block size.  
& : A-E Identifies the bank for this fleet block.  
# : 0-7 Identifies the Fleet map Block No.

- ② **FB & # %%[\$r]** : Program Fleet Block No  
& : A-E Identifies the bank for this Fleet Block.  
# : 0-7 Identifies the Fleet map Block No.  
%% : 00-14 Block size indicator.

Radio → Controller

- ① **FB & # %%[\$r]** : Programmed fleet Block size.  
& : A-E Identifies the bank for this fleet block.  
# : 0-7 Identifies the Fleet map block No.  
%% : 00-14 Block size indicator.

- ② **OK[\$r]**

=====

**FI** : Confirm/Set Frequency Identification function

=====

Controller → Radio

- ① **FI[\$r]** : Confirm Frequency Identification function ON/OFF
- ② **FIN[\$r]** : Frequency Identification ON
- FIF[\$r]** : Frequency Identification OFF

Radio → Controller

- ① **FIN[\$r]** : ON
- FIF[\$r]** : OFF

- ② **OK[\$r]**

This command instructs the unit to turn or confirm Frequency Identification function ON/OFF.

=====

**HA** : informs when highway alert condition changes.

=====

Controller → Radio

- ① HA[¥r] : Confirm “HA” command is active or inactive
- ② HAN[¥r] : activate “HA” command
- HWF[¥r] : deactivate “HA” command

Radio → Controller

- ① HAN[¥r] : activate “HA” command
- HAF[¥r] : deactivate “HA” command
- ② OK[¥r]

This command instructs the unit to turn the function ON/OFF.

While the function is ON, the unit is monitoring the alert condition and informs when it changes. While the function is activate, if the highway alert condition becomes

- “NO ALERT” to “ALERT”, unit sends HA+[¥r] to the controller.
- “ALERT” to “NO ALERT”, unit sends -[¥r] to the controller.

=====

**HP** : informs when highway alert signal receive.

=====

Controller → Radio

- ① HP[¥r] : Confirm “HP” command is active or inactive
- ② HPN[¥r] : activate “HP” command
- HPF[¥r] : deactivate “HP” command

Radio → Controller

- ① HPN[¥r] : activate “HP” command
- HPF[¥r] : deactivate “HP” command
- ② OK[¥r]

This command instructs the unit to turn the function ON/OFF.

While the function is ON, the unit is monitoring the alert signal status and informs.

While the function is activate, if the highway alert signal will be active, the unit sends “HP ALERT” to the controller.

=====

**HW** : Confirm/Set Highway scan mode

=====

Controller → Radio

- ① HW[¥r] : Confirm Highway scan mode
- ② HWN[¥r] : Highway scan only mode
- HW+[¥r] : Highway scan plus private memory scan

Radio → Controller

- ① HWN[¥r] : Highway scan only mode
- HW+[¥r] : Highway scan plus private memory scan
- ② OK[¥r]

=====

**IC** : Confirm/Move/Program Talk Group ID Location No.

=====

Controller → Radio

- ① IC[¥r] : Confirm ID Location Number
- ② IC @%[¥r] : Move ID memory
  - @ : ID Scan list (A-E)
  - % : ID Location (1-9, 0)

"0" is used to indicate "ID Location 10".

<Example>

IC A0[¥r]

Move ID Memory No. to "ID Scan List A" and "ID Location 10".

- ③ Program Talk Group ID

/// MOTORIZLA TYPE1 ///

IC @% &##-\$[¥r] or IC @% &###-\$[¥r]

- @% : ID Memory No.
- @ : ID Scan List (A-E)
- % : ID Location (1-9, 0)
- &##-\$ : Type1 ID
- & : Block No.(0-9)
- ## (or ###) : Fleet No.

< BCT8 OPERATION SPECIFICATION >

\$\$ : Sub fleet No.

<Example>

IC A0 001-05[¥r] : ID in ID memory "A10" is  
"BLOCK=0, FLEET=1, SUBFLEET=5".

/// MOTOROLA TYPE 2 ///

IC @% #####[¥r]

@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9, 0)  
##### : Type2 ID

<Example>

IC A0 001234[¥r] : ID in ID memory "A10" is "1234".

/// LTR ///

IC @% %\$####[¥r]

@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9,0)  
%\$#### : LTR Talk Group ID  
% : Area code (0, 1)  
\$ : Home Repeater No. (01-20)  
## : ID(000-254)

<Example>

IC A0 001064[¥r] : ID memory "A10"  
: Area code: "0"  
: Home Repeater No.: "01"  
: ID: "64"

/// EDACS ///

IC @% &&-\$#[¥r]

@% : ID Memory No.  
@ : ID Scan List (A-E)

< BCT8 OPERATION SPECIFICATION >

% : ID Location (1-9, 0)  
&&-\$ : Edacs Talk Group ID  
&& : Agency No.  
## : Fleet No.  
\$ : SUBFLEET No.

<Example>

IC A0 01-025[¥r] : AFS format  
IC A0 000149[¥r] : DECIMAL format  
ID memory No : "A10"  
AGENCY=01, FLEET=02, SUBFLEET=5"

Radio → Controller

①,②

//// Not Programmed ID ////

IC @% -----[¥r]  
@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9, 0)

//// MOTOROLA TYPE1 ////

IC @% &##-\$[¥r] or IC @% &###-\$[¥r]  
@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9, 0)  
&##-\$ : Type1 ID  
& : Block No.(0-7)  
##(or ###) : Fleet No.  
\$\$ : Sub fleet No.

<Example>

IC A0 001-05[¥r] : Talk Group ID in ID memory "A10" is  
"BLOCK=0, FLEET=1, SUBFLEET=5".

/// MOTOROLA TYPE 2 ///

IC @% #####[\$r]

@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9, 0)  
##### : Type2 ID

<Example>

IC A0 001234[\$r] : Talk group ID in ID memory "A10" is "1234".

/// LTR ///

IC @% %\$##[\$r]

@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9, 0)  
%\$## : LTR Talk Group ID  
% : Area code(0,1)  
\$ : Home Repeater No. (01-20)  
## : ID(000-254)

<Example>

IC A0 001064[\$r]

Talk group ID in ID memory "A10" is "Area code:0, Home Repeater No:01, ID:64"

/// EDACS ///

IC @% &&-##[\$r]

@% : ID Memory No.  
@ : ID Scan List (A-E)  
% : ID Location (1-9, 0)  
&&-## : Edacs Talk Group ID  
&& : Agency No.  
## : Fleet No.  
\$ : SUBFLEET No.

<Example>

IC A0 01-025[\$r] AFS format

IC A0 000149[¥r] DECIMAL format

Talk Group ID in ID memory "A10" is "AGENCY=01, FLEET=02, SUBFLEET=5"

③ OK[¥r]

=====  
**ID** : informs when ID reception starts or ends  
=====

Controller → Radio

- ① ID[¥r] : confirm "ID" command active
- ② IDN[¥r] : "ID" command ON
- IDF[¥r] : "ID" command OFF

Radio → Controller

- ① IDN[¥r] : "ID" command ON
- IDF[¥r] : "ID" command OFF
- ② OK[¥r]

While the function is ON, the reception ID and tuned frequency are returned by the following format when a radio receives ID and when the reception of ID is finished.

(1) ID Reception Starts

/// MOTOROLA TYPE1 ///

ID S &##-\$% %%%% %%%%[¥r]  
Or      ID S &##-\$% %%%% %%%%[¥r]

&##-&& / &##-\$ :Motorola Type1 ID  
& : Block No. ## / ## :Fleet No.  
\$\$ / \$ : Subfleet No.  
%%%% %%%% : Control channel Frequency

<Example>

ID S 001-03 08510125[¥r]

ID reception starts on Block=0, Fleet=1, Subfleet=3

Control channel Frequency: 851.0125MHz

**//// MOTOROLA TYPE 2 ////**

ID S @@@@ @@@@ %%%%%%%%[¥r]

@@@@@@@ : Talk group ID

%%%%%%% : Control channel Frequency

<Example>

ID S 001234 08510125[¥r]

ID reception starts on "ID=1234". Control Channel Frequency:851.0125MHz

**//// LTR ////**

ID S %\$## %%%%[¥r]

%\$## : LTR Talk Group ID

% : Area code(0,1)

\$\$ : Home Repeater No. (01-20)

## : ID(000-254)

%%%%%%% : Home channel Frequency

<Example>

ID S 001064 08510250[¥r]

ID reception starts on "Area code:0 Home Repeater No.:01 ID:64".

Home Channel Frequency:851.0250MHz

**//// EDACS ////**

ID S &&-##\$ %%%%[¥r]

&&-##\$ : EDACS Talk Group ID

&& : Agency

## : Fleet No. \$ :SUBFLEET No.

%%%%%%% : Voice channel Frequency

<Example>

ID S 01-025 08510125[¥r] : AFS format

ID S 000149 08510125[¥r] : DECIMAL format

(2)ID reception ends

**//// MOTOROLA TYPE1 ////**

ID E &##-\$% %%%% %%%[%r]

Or ID E &###-\$% %%%% %%%[%r]

&##-&& / &###-\$ : Motorola Type1 ID

& : Block No.

## / ### : Fleet No.

\$\$ / \$ : Subfleet No.

%%%%%% : Voice channel Frequency

<Example>

ID E 001-03 08510125[%r] ID reception ends on Block=0,  
Fleet=1, Subfleet=3  
Voice channel Frequency:851.0125MHz

**//// MOTOROLA TYPE2 ////**

ID E @@@@ @@@@ %%%% %%%[%r]

@@@@@@@ : Talk group ID

%%%%%% : Voice channel Frequency

<Example>

ID E 001234 08510125[%r] ID reception ends on "ID=1234".  
Voice channel Frequency:851.0125MHz

**//// LTR ////**

ID E %\$## %%%% %%%[%r]

%\$## : LTR Talk Group ID

% : Area code(0,1)

\$\$ : Home Repeater No. (01-20)

### : ID(000-254)

%%%%%% : GOTO channel Frequency

<Example>

ID E 001064 08510250[¥r]

ID reception ends on "Area code:0 Home Repeater No.:01 ID:64".

GOTO Channel Frequency:851.0250MHz

**//// EDACS ////**

ID E &&-\$%\$%%%[%[¥r]

&&-\$%\$ : EDACS Talk Group ID

&& : Agency

## : Fleet No.

\$ : SUBFLEET No.

%%%-%-%-% : Working channel Frequency

<Example>

ID E 01-025 08510125[¥r] : AFS format

ID E 000149 08510125[¥r] : DECIMAL format

=====

**IL** : Read / Register / Delete L/O ID memory

=====

Controller → Radio

① Read

IL###[¥r]

### : Lockout Memory No.(001 - 100)

: Highway Trunked ID lockout memory No. (101-130)

② Register

**//// MOTOROLA TYPE 1 ////**

ILR &-\$%\$[¥r]

Or ILR &-\$%\$-\$[¥r]

&-\$%\$ / &-\$%\$-\$ : Motorola Type1 ID

& : Block No.

## / ## : Fleet No.

\$\$ / \$\$ : Subfleet No.

<Example>

ILR 001-03[¥r]

**//// MOTOROLA TYPE 2 ////**

ILR @@@@@@@[¥r]

@@@@@@@ : MOTOROLA TYPE2

<Example>

ILR 024106[¥r]

**//// LTR ////**

ILR %\$####[¥r]

%\$#### : LTR Talk Group ID

% : Area code(0,1)

\$\$ : Home Repeater No. (01-20)

### : ID(000-254)

<Example>

ILR 001064[¥r]

**//// EDACS ////**

ILR &&-##\$[¥r]

&&-##\$ : EDACS Emergency ID

&& : Agency

## : Fleet No.

\$ : SUBFLEET No.

<Example>

ILR 01-011[¥r]

**>> EDACS BLOCKOUT <<**

ILR &&-¥r : ALL Agency lockout

&& : Agency No

ILR &&-##¥r : ALL Agency-Fleet lockout

## : Fleet No.

<Example>

ILR 02-¥r

ILR 02-01[¥r]

③ Delete

//// MOTOROLA TYPE 1 ////

ILD &##-\$[\$r] / ILD &##-\$[\$r]

&##-&&

or &##-\$ :Motorola Type1 ID

& : Block No.

## / ### : Fleet No.

\$\$ / \$ : Subfleet No.

<Example>

ILD 001-03[\$r]

//// MOTOROLA TYPE 2 ////

ILD @@@@[@@[\$r]

@@@@[@@ : MOTOROLA TYPE2

<Example>

ILD 024106[\$r]

//// LTR ////

ILD %\$##[\$r]

%%% : LTR Talk Group ID

% : Area code(0,1)

\$\$ : Home Repeater No. (01-20)

### : ID(000-254)

<Example>

ILD 001064[\$r]

//// EDACS ////

ILD &&-\$[\$r]

&&-\$ : EDACS Emergency ID

&& : Agency

## : Fleet No.

\$ : SUBFLEET No.

<Example>

ILD 01-011[¥r]

>> EDACS BLOCKOUT <<

ILD &&-[¥r] : ALL Agency lockout  
&& : Agency No  
ILD &&-#[¥r] : ALL Agency-Fleet lockout  
## : Fleet No.

<Example>

ILD 02-[¥r]

ILD 02-01[¥r]

/// Highway Trunking Talkgroups ///

ILD###-[¥r]

### : Highway Trunked ID lockout memory No. (101-130)

<Example>

ILD101[¥r]

Radio → Controller

① Read

//// NOT REGISTERED LOCKOUT ID MEMORY ////

IL -----[¥r]

/// MOTOROLA TYPE 1 ///

IL &##-\$-[¥r]

Or IL &##-\$-[¥r]

&##-&&

&##-\$ : Motorola Type1 ID  
& : Block No. ## / ### :Fleet No.  
\$\$ / \$ : Subfleet No.

<Example>

IL 001-03[¥r]

//// MOTOROLA TYPE 2 ////

IL @@@@[@@@@[\$r]  
      @@@@[@@@] : MOTOROLA TYPE2

<Example>

IL 024106[\$r]

//// LTR ////

IL %\$###[\$r]  
      %\$### : LTR Talk Group ID  
      % : Area code(0,1)  
      \$ : Home Repeater No. (01-20)  
      ### : ID(000-254)

<Example>

IL 001064[\$r]

//// EDACS ////

IL &&-###[\$r]  
      &&-### : EDACS Emergency ID  
      &&:Agency #:#:Fleet No. \$: SUBFLEET No.

<Example>

IL 01-011[\$r]

>> EDACS BLOCKOUT <<

IL &&---[\$r] : ALL Agency lockout  
ILD &&-#-[¥r] : ALL Agency-Fleet lockout  
      && : Agency  
      ## : Fleet No.

<Example>

IL 02-[¥r]

IL 02-01-[¥r]

## /// Highway Trunking Talkgroups ///

IL ##### % % % % % % % % [¥r]

##### : Highway Trunked ID

%%%%%%%%%%%%: control channel frequency

## ② Register

If the ID is registered into L/O ID memory, the unit sends OK[¥r] to the controller.

If the ID is already in L/O ID memory, sends ON[¥r].

If L/O ID memory is full, sends **FULL[¥r]**.

Note) the scanner can not register a highway trunking talkgroup.

### ③ Delete

If the ID is deleted from L/O ID memory, the unit sends OK[¥r] to the controller. If the ID isn't in L/O ID memory, sends OFF[¥r].

Note) the scanner does not send "OFF" for highway trunking talkgroup.

**IS** : Confirm/Select ID scan lists.

Controller → Radio

① IS[¥r] : Confirm ID scan list name

@,%,O,· · · : ID scan list No. (A-E)

### <Example>

IS ACE[¥r] Select "LIST A, LIST C, LIST E".

(LIST B, LIST D are not selected)

### Radio → Controller

1, 2

### <Example>

IS ACE[¥r] Selected ID scan lists are "LIST A, C, E".

This command instructs the unit to make designated ID scan lists be selected.

=====

**KEY** : KEY emulation command

=====

Controller → Radio

KEYOO[¥r]      OO:KEY Emulate Code (see Following Table)

\* To indicate "Hold Press" of each key, add "H" to each command.

<Example>

KEY06H[¥r]      : This command is used instead of hold press of [L/O] key.

KEY02 6[¥r]      : This command is used instead of press of [6] key.

Radio → Controller

OK[¥r]

Key Emulate Code:

KEY00 : [RESUMU/HOLD]	KEY01 : [HWY/PVT]
-----------------------	-------------------

KEY02 : [0]-[9]	KEY03 : [.]
-----------------	-------------

KEY04 : [E]	KEY05 : [PRI]
-------------	---------------

KEY06 : [L/O]	KEY07 : [▲]
---------------	-------------

KEY08 : [▼]	KEY09 : [SRCH]
-------------	----------------

KEY10 : [SVC]	KEY11 : [DATA]
---------------	----------------

KEY12 : [DLY]	KEY13 : [TRUNK]
---------------	-----------------

KEY14 : [STATE]	KEY15 : [MUTE]
-----------------	----------------

KEY16 : [FLASH]	KEY17 : [ALERT]
-----------------	-----------------

=====

LCD : Read LCD

=====

Controller → Radio

- ① LCD @[\$r] : Read each icon status  
    @## : Specific icon symbol (see following)
- ② LCD BNK[\$r] : Check the selected bank No.
- ③ LCD CHN[\$r] : Check the CH indication part
- ④ LCD FRQ[\$r] : Check the FREQUENCY indication part
- ⑤ LCD[\$r] : Read all status at once

Radio → Controller

- ① @## + : specific icon is stay ON
- @## - : specific icon is stay OFF
- @## \* : specific icon is flashing

	ICON	@##		ICON	
1	TRUNK	TRUNK	16	CB	CB
2	P	P	17	AIR	AIR
3	E	E	18	RR	RR
4	M	M	19	MRN	MRN
5	L	L	20	HOLD	HOLD
6	BANK	BANK	21	▲	UP
7	LIST	LIST	22	SRCH	SRCH
8	M-LOCK	MLOCK	23	▼	DOWN
9	RMT	RMT	24	PRI	PRI
10	HWY	HWY	25	L/O	LOUT
11	PVT	PVT	26	DLY	DLY
12	POL	POL	27	DATA	DATA
13	WX	WX	28	FLASH	FLASH
14	FIRE/EMS	FIRE	29	.	DCML
15	NEWS	NEWS	-	-	-

②

<EXAMPLE>

BNK +---[¥r] : ON:1, 2 OFF:4, 5 FLASH:3

③

<EXAMPLE>

CHN [250] [ ] [¥r]

CHN [ AK] [ \*\*] [¥r]

CHN [1-1] [\*\*\*] [¥r]

④

<EXAMPLE>

FRQ [956.0000] [ ] [¥r]

FRQ [id SCAN] [ ] [¥r]

⑤

all above at once.

---

**LO** : Confirm/Set LOCKOUT Channel

---

Controller → Radio

① LO[¥r] : Confirm LOCKOUT function ON/OFF

② LON[¥r] : Lockout ON

LOF[¥r] : Lockout OFF

Radio → Controller

① LON[¥r] : Lockout ON

LOF[¥r] : Lockout OFF

② OK[¥r]

This command instructs the unit to turn or confirm LOCKOUT function ON/OFF.

=====

**MA** : Confirm / Move the channel No.

=====

Controller → Radio

① **MA[¥r]** : Confirm

② **MA@[@@][¥r]** : Move to  
      @@@ : channel No. (001-250)

<Example>

**MA015[¥r]** Move to the channel No. "15".

Radio → Controller

①,②

**C@[@@ F%%%%%%%%% T# D# L# A# R# N\$\$\$ [¥r]**

      @@@ : Channel No.

      %%%%%%%%% : Frequency

The order of the frequency digits are from 1 GHz digit to 1GHz digit.

**#** :N or F(ON/OFF)

      TN/TF :Trunking frequency / conventional frequency

      DN/DF : Delay ON/OFF

      LN/LF : Lockout ON/OFF

      AN/AF : Attenuator ON/OFF

      RN/RF : Auto record function ON/OFF

**N** :CTCSS /DCS status

**\$\$\$** :CTCSS/DCS TONE No.

<Example>

**C015 F04060125 TF DN LF AF N000[¥r]**

The current channel No. is "15",

and its conventional frequency is "406.0125 MHz".

Delay function is ON, Lockout is OFF,

Attenuation is OFF

CTCSS is not programmed.

=====

**MD** : Confirm the Scanner mode

=====

Controller → Radio

MD[¥r]

Radio → Controller

MD@@[¥r] @@ :Current scanner mode No.(See following Table)

This command instructs the unit to confirm the current scanner mode .

- 00: Private Scan mode
- 01: Private Scan hold mode
- 02: Band Search mode
- 03: Band Search Hold mode
- 04: Service Scan mode
- 05: Service Scan Hold mode
- 06: Highway Scan mode
- 07: Highway Scan Hold mode
- 08: Highway Trunking mode
- 09: Highway Trunking Hold mode
- 10: Program channel mode
- 11: Motorola ID search mode
- 12: Motorola ID search hold mode
- 13: Motorola ID scan mode
- 14: Motorola ID manual mode
- 15: Edacs ID search mode
- 16: Edacs ID search hold mode
- 17: Edacs ID scan mode
- 18: Edacs ID manual mode
- 19: LTR ID search mode
- 20: LTR ID search hold mode
- 21: LTR ID scan mode
- 22: LTR ID manual mode
- 23: Manual frequency mode
- 24: Program trunked bank menu
- 25: Remote control menu

=====

**MU** : Confirm/Set status of speaker muting.

=====

Controller → Radio

- ① MU[¥r] :Confirm MUTE control mode.
- ② MU?[¥r] :Confirm ON/OFF condition.
- ③ MUN[¥r] :Set MUTE ON(by force)mode.
- MUF[¥r] :Set MUTE OFF(by force)mode.
- MUA[¥r] :Set AUTO MUTE control mode.

Radio → Controller

- ① MUN[¥r] :MUTE ON(by force)mode.
- MUF[¥r] :MUTE OFF(by force)mode.
- MUA[¥r] :AUTO MUTE control mode.
- ② MU ON[¥r] :MUTE ON condition.
- MU OFF[¥r] :MUTE OFF condition.
- ③ OK[¥r]

this command instructs the unit to set or confirm the status of speaker Muting.

=====

**PC** : Confirm/Set priority channel No. of a bank.

=====

Controller → Radio

- ① PC @[%r] :Confirm
- @ :Bank No.(A-E)

<Example>

PC A[¥r] Confirm the priority channel of "Bank A".

- ② PC @%%[%r] : Set
- @ : Bank No.(A-E)
- %% : Channel No.(001 - 250)

<Example>

PC A014[¥r] : Set the priority channel of "Bank A" to "14".

Radio → Controller

①,②

PC @%%%[¥r]

@ : Bank No.(A-E)

%%% : Channel No. (001 - 250)

<Example>

PC A014[¥r] : The priority channel of "Bank A" is "14"

---

PI : Confirm/Set Priority Talk ID Memory Location

---

Controller → Radio

① PI @[%r] : Confirm Priority ID location

@ : ID list No. (A-E)

<Example>

PI A[¥r]

: Confirm priority Location of List "A" in current Trunk Bank

② PI @#[¥r] : Set Priority ID location

@ : ID List No. (A-E)

# : ID location No. (1-9,0)

<Example>

PI A1[¥r] : set priority to List "A", Location "1"

Radio → Controller

① PI @# %%%%[%r]

@ : ID List No (A-E)

# : ID location No. (1-9,0)

%%%%% : Talk Group ID

<Example>

PI A1 001234[¥r] : Priority of List "A" is location "1" ID:001234

② OK[¥r]

=====

**PM** : Read / Program a channel frequency

=====

Controller → Radio

① **PM@[@@[\$r]** : Read channel frequency

      @[@@ : Channel No. (001-250)

<Example>

PM014[\$r]            Read the frequency of "14CH".

② **PM@[@@ %%%%%%[\$r]** : Program channel frequency

or   **PM@[@@T%%%%%[\$r]**

      @[@@ : Channel No.(001-250)

      T       : Trunking channel flag

      %%%%%% : Frequency

The order of the frequency digits are from 1 GHz digit to 100 Hz digit.

PM command initialize delay mode, because DL commands is commanded after commanding PM command.

<Example 1> program 406.0125MHz to Channel No.14

PM014 04060125[\$r]        :Set the frequency of "14CH" to "406.0125 MHz".

Radio → Controller

①,②

**C@[@@ F%%%%% T# D# L# A# R# N\$\$\$ [\$r]**

      @[@@ : Channel No. (001-250)

      %%%%% : Frequency

      # :N or F(ON/OFF)

      ex)TN/TF : trunking / conventional frequency

      DN/DF : Delay ON/OFF

      LN/LF : Lockout ON/OFF

      AN/AF : Attenuator ON/OFF

      RN/RF : Auto record function ON/OFF

      \$\$\$ :CTCSS/DCS TONE No.

<Example>

C015 F04060125 TF DN LF AF RF N000[\$r]

      CH No       : CH15

FREQUENCY : "406.0125 MHz"(conventional)  
DELAY : ON  
LOCKOUT : OFF  
ATTENUATOR : OFF  
CTCSS : 00.0 Hz.

=====

**PR** : Confirm/Set PRIORITY function

=====

Controller → Radio

- ① PR[¥r] :Confirm priority function ON/OFF
- ② PRN[¥r] :Set priority function
- PRF[¥r] :Priority function OFF
- PR+[¥r] :Set Priority Only function (only used Highway scan)

Radio → Controller

- ① PRN[¥r] :Priority is ON
- PRF[¥r] :Priority is OFF
- PR+[¥r] :Priority Only is ON (only used Highway scan)
- ② OK[¥r]

This command instructs the unit to turn or confirm PRIORITY(and Only) function ON/OFF.

=====

**QU** : informs when squelch condition changes.

=====

Controller → Radio

- ① QU[¥r] : Confirm QU command active
- ② QUN[¥r] : QU command ON
- QUF[¥r] : QU command OFF

Radio → Controller

- ① QUN[¥r] : QU command is ON
- QUF[¥r] : QU command is OFF
- ② OK[¥r]

While the function is ON, if the squelch condition becomes

- Close to open, unit sends +[¥r] to the controller.
- Open to close, unit sends -[¥r] to the controller.

This command instructs the unit to turn the function ON/OFF.

While the function is ON, the unit is monitoring the squelch condition and informs when it changes.

=====

**RF** : Confirm/Tune the commanded frequency.

=====

Controller → Radio

- ① RF@@@@@@@[¥r]  
Or RF@@@@@@@?@[¥r]

The order of the digits are from 1 GHz digit to 100 Hz digit.

<Example>

RF04060125[¥r] tuned receiver to 406.0125 MHz

RF00290038[¥r] tuned receiver to 29.0050MHz(rounded with default step)

if you wish to confirm the tuned frequency for this command response, a "?" code add after the commanded frequency.

- ② RF[¥r] :confirm tuned frequency

Radio → Controller

- ① OK[¥r]  
Or RF@@@@@@@[¥r]
- ② RF@@@@@@@[¥r]  
@@@@@@@ : Tuned frequency

This command can be instantly tuned to a commanded frequency .

=====

**RG** : Confirm /Set EDACS ID Range mode.

=====

Controller → Radio

① Confirm ID Range mode

RG[¥r]

② RG @@-[¥r] : Set ID Range mode

Or RG @@##[¥r]

@@ : EDACS id (Agency:00-15)

## : EDACS id (Fleet:00-15)

<Example>

RG 01-[¥r]

or RG 01-01[¥r]

③ Clear ID Range mode

RGF [¥r]

Radio → Controller

① RGN[¥r] : Range mode ON

RGF[¥r] : Range mode OFF

② OK[¥r]

③ OK[¥r]

=====

**RI** : informs when priority receiving condition changes

=====

Controller → Radio

① RI[¥r] : Confirm "RI" command active

② RIN[¥r] : Activate "RI" command

RIF[¥r] : Inactivate "RI" command

Radio → Controller

① RIN[¥r] : "RI" command is ACTIVE

RIF[¥r] : "RI" command is INACTIVE

② OK[¥r]

While the function is ON,

· if the unit stops on the priority channel by priority receiving, sends PST[¥r] to the controller.

- if the unit returns from the priority channel, sends PRT[¥r] to the controller.

This command instructs the unit to turn the function ON/OFF. While the function is ON, the unit is monitoring the priority receiving condition and informs when it changes.

**RM** : Confirm receive mode.

Controller → Radio

"RM[¥r]"

## Radio → Controller

RM @@[¥r] : Confirm receive mode

@@ :Current Receiver modulation

### <Example>

RM AM[¥r] : AM

RM FM[¥r] : FM

This command instructs the unit to confirm receiver modulation.

This command is acceptable at conventional/trunking mode.

**SB** : Confirm/Select scan banks.

Controller → Radio

①SB[¥r] :Confirm scan banks

@%.O,---:bank name

### <Example>

SB ACE[¥r1

Select "BANK A. C. E".

## Radio → Controller

<Example>

SB ACE[¥r] Selected scan banks are "BANK A, C, E".

This command instructs the unit to make designated scan banks be selected.

=====

**SI** : Confirm Scanner Information

=====

Controller → Radio

SI[¥r]

Radio → Controller

SI @@@@@@@@,%%%%%%%%%%%%%,&&&[¥r]

@@@@@@@ : Alphanumeric model Name/No.

%%%%%%%%%% : Alphanumeric ESN No.(Not used)

&&& : Remote Command Version.

<Example>

SI BCT8,0000000000,105

This is the information string sent by the scanner to PC

=====

**SQ** : Confirm squelch condition.

=====

Controller → Radio

SQ[¥r]

Radio → Controller

+[¥r] : Now squelch is OPEN.

-[¥r] : Now squelch is CLOSE.

This command instructs the unit to send whether the squelch is OPEN or CLOSE.

**SS** : Read / Register a frequency in search skip memory

Controller → Radio

① Read

SS### ### : Skip Memory No. (001-400)  
001-100: for Band search  
101-150: for Highway Patrol Priority channel  
151-250: for Highway Patrol Other channel  
251-350: for Police and DOT service search  
351-400: for Other service search

## ② Register

The order of the digits are from 1 GHz digit to 100 Hz digit.

This register command is applied only to band search frequency.

### <Example>

SS04060125[¥r] Register 406.0125 MHz into search skip memory.

Radio → Controller

## ① Read

<Band search, Highway patrol channel>

ss@@@@@@@ [¥r]  
@@@@@@@ : Frequency

### < Service search >

SS@{@@#@#@#@#@ #[\$r]  
@{@@#@#@#@@ : Frequency  
# : service kind (see "COMMAND SV")

### <Example>

SS04060125[¥r]

Frequencies in search skip memory are "406.0125 MHz"

SS08594875 1

Skip Frequencies in Police bank are "859.4875 MHz"

② Register

SS@#####[@][¥r] @#####[@] : Frequency

<Example>

SS04060125[¥r] 406.0125 MHz is registered.

※ If the frequency is already in search skip memory,  
the unit sends ON[¥r] to the controller.

This command instructs the unit

- ① to send the frequencies in search skip memory.
- ② to register a frequency into search skip memory.

=====

**ST** : Confirm frequency step

=====

Controller → Radio

- ① ST[¥r] : Confirm frequency step

Radio → Controller

- ① ST ##[¥r] : Inform frequency step
- ##[¥r]: 5K / 12.5K

=====

**SV** : Confirm/Set Service scan mode

=====

Controller → Radio

- ① SV[¥r] : Confirm Service kind
- ② SV@[¥r] : Set Service scan mode
- @ : service kind
  - 1: Police service                   2: Weather service scan
  - 3: FIRE/EMS service               4: NEWS service scan
  - 5: CB service scan               6: Air service
  - 7: Rail road service              8: Marine service
  - 9: Department of transportation service

< BCT8 OPERATION SPECIFICATION >

Radio → Controller

① SV@[¥r] : Set Service scan mode  
@ : service kind  
1: Police service      2: Weather service scan  
3: FIRE/EMS service      4: NEWS service scan  
5: CB service scan      6: Air service  
7: Rail road service      8: Marine service  
9:Department of transportation service

② OK[¥r]

=====

**TB** : Confirm/Set Trunking bank On/Off

=====

Controller → Radio

① TB[¥r] : Confirm Active trunk Bank ON or OFF  
② TB #[¥r] : Confirm optional trunk bank ON or OFF  
# : Bank No.(A-E)  
③ TBN #[¥r] : Set Trunking Bank to ON  
# : Bank No.(A-E)  
TBF #[¥r] : Set Trunking Bank to OFF  
# : Bank No.(A-E)

Radio → Controller

①,②  
TB # @@@@ @ %@ [¥r]  
# : Active/Optional Trunking Bank (A-E)  
@:@:@:@ : Trunking Type  
E2-800(Motorola Type2 800MHz)  
E2-VHI(Motorola Type2 VHI)  
E2-UHF(Motorola Type2 UHF)  
TYPE1 (Motorola Type1)  
EDCS WIDE (WIDE BAND EDACS)  
EDCS SCT  
LT (LTR)  
% : Trunking bank ON or OFF  
N: Trunking ON

F: Trunking OFF

<Example> TB A E2-800 N[¥r]

Active Bank: "A" Trunk Type: MOTOROLA TYPE2 800MHz TRUNK ON

③ OK[¥r]

=====

**TC** : Confirm/Set Control channel only mode

=====

Controller → Radio

① Confirm "CONTROL CH ONLY MODE" is ON or OFF

TC @[¥r] @ :Bank No. (A-E)

② Set "CONTROL CH ONLY MODE" to ON or OFF

TCN @ ##[¥r] :Set "CONTROL CH ONLY MODE" to ON

@ :Bank No. (A-E)

## :CH assignment plan(optional) P1,P2,P3,P4

P1: Plan1 P2: Plan2 P3: Plan3 P4: Plan4

<Example>

TCN A P1[¥r] : set control channel only mode to plan1

TCF @[¥r] : control channel only mode OFF

Radio → Controller

① TCN @ ##[¥r] : "CONTROL CH ONLY MODE" is ON

@ :Bank No. (A-E)

## :CH assignment plan(optional) P1,P2,P3,P4

P1: Plan1 P2: Plan2 P3: Plan3 P4: Plan4

TCF @[¥r] : "CONTROL CH ONLY MODE" is OFF

<Example>

TCN A P1[¥r]

or TCN A[¥r]

TCF @[¥r] : control channel only mode OFF

② OK[¥r]

=====

**TD** : Confirm/Set Motorola disconnect Tone option

=====

Controller → Radio

- ① TD[¥r] : Confirm disconnect tone (end of tone) option
- ② TDN[¥r] : disconnect tone option ON
- TDF[¥r] : disconnect tone option OFF

Radio → Controller

- ① TDN[¥r] : Disconnect tone option ON
- TDF[¥r] : Disconnect tone option OFF
- ② OK[¥r]

Note:

if you add the bank No(A-E) at the end , you can select your optional bank.  
Ex) "TD A" Or "TDN A"

This command instructs the unit to turn or confirm Disconnect tone option ON/OFF.

=====

**TG** : Program Talk Group ID

=====

Controller → Radio

- ① TG ? @%[¥r] :Confirm Programmed Talk Group IDs

    ? :Bank No.(A-E)

    @:ID Scan list(A-E)

    %:ID Location (1-9,0)

- ② Program Talk Group IDs

/// MOTOROLA TYPE1 ///

TG ? @% &##-\$[\$¥r] or TG ? @% &###-\$[\$¥r]

    ? : Bank No.(A-E)

    @% : ID Memory No.

    @ :ID Scan List (A-E)   % :ID Location (1-9,0)

    &##-\$\$ : Type1 ID

    & :Block No.(0-7)

< BCT8 OPERATION SPECIFICATION >

## or ### :Fleet No.

\$\$ :Sub fleet No.

<Example>

TG AA0 001-05[¥r] ID in ID memory "BANK A-A10" is  
"BLOCK=0, FLEET=1, SUBFLEET=5".

TG AA0 0127-3[¥r] ID in ID memory "BANK A-A10" is  
"BLOCK=0, FLEET=127, SUBFLEET=3".

//// MOTOROLA TYPE 2 ////

TG ? @% #####[¥r]

? : Bank No.(A-E)

@% : ID Memory No.

@ :ID Scan List (A-E) % :ID Location (1-9,0)

##### : Type2 ID

<Example>

TG AA0 001234[¥r] Talk Group ID in id memory "BANK A-A10" is "1234".

//// LTR ////

TG ? @% %\$###[¥r]

? : Bank No.(A-E)

@% : ID Memory No.

@ :ID Scan List (A-E) % :ID Location (1-9,0)

%\$### : LTR Talk Group ID

% :Area code(0,1)

\$\$ :Home Repeater No. (01-20)

### :ID(000-254)

<Example>

TG AA0 001064[¥r]

ID in ID memory "BANK A-A10" is "Area code:0 Home Repeater No.:01 ID:64"

//// EDACS ////

TG ? @% &&-##\$[¥r]

? : Bank No.(A-E)

@% : ID Memory No.

@ : ID Scan List (A-E)  
% : ID Location (1-9,0)  
&&-\$ : Edacs Talk Group ID  
  && : Agency No.(00-15)  
  ## : Fleet No.(00-15)  
  \$ : SUBFLEET No.(0-7)

<Example>

TG AA0 01-025[¥r] : AFS format  
TG AA0 000149[¥r] : DECIMAL format

ID in ID memory "BANK A-A10" is "AGENCY=01, FLEET=02, SUBFLEET=5"

>> PROGRAM EDACS PARTIAL ID <<

TG ? @% &&-[¥r]  
Or      TG ? @% &&-\$-[¥r]  
  ? : Bank No.(A-E)  
  @% : ID Memory No.  
    @ : ID Scan List (A-E)  
    % : ID Location (1-9,0)  
    &&- : Edacs Partial Talk Group ID(All Agency)  
    &&-\$ : Edacs Partial Talk Group ID(All Agency-Fleet)  
    && : Agency No.(01-15)  
    ## : Fleet No.(00-15)

<Example>

TG AA0 01-[¥r]  
TG AA0 01-02[¥r]

Radio → Controller

①

/// MOTOROLA TYPE1 ///

TG ? @% &-\$-[¥r] or TG ? @% &-\$-[¥r]

? : Bank No.(A-E)  
@% : ID Memory No.  
  @ : ID Scan List (A-E)  
  % : ID Location (1-9,0)  
  &-\$ : Type1 ID  
  & : Block No.(0-9)

## or ### :Fleet No.

\$\$ : Sub fleet No.

<Example>

TG AA0 001-05[¥r] ID in ID memory "BANK A-A10" is  
"BLOCK=0, FLEET=1, SUBFLEET=5".

/// MOTOROLA TYPE 2 ///

TG ? @% #####[¥r]

? : Bank No.(A-E)

@% : ID Memory No.

@ : ID Scan List (A-E)

% : ID Location (1-9,0)

##### : Type2 ID

<Example>

TG AA0 001234[¥r] ID in ID memory "BANK A-A10" is "1234".

/// LTR ///

TG ? @% %\$###[¥r]

? : Bank No.(A-E)

@% : ID Memory No.

@ : ID Scan List (A-E)

% : ID Location (1-9,0)

%\$### : LTR Talk Group ID

% : Area code(0,1)

\$\$ : Home Repeater No. (01-20)

### : ID(000-254)

<Example>

TG AA0 001064[¥r]

ID in ID memory "BANK A-A10" is "Area code:0 Home Repeater No.:01 ID:64"

/// EDACS ///

TG ? @% &&-##\$[¥r]

? : Bank No.(A-E)

@% : ID Memory No.

@ : ID Scan List (A-E)

< BCT8 OPERATION SPECIFICATION >

% : ID Location (1-9,0)  
&&-\$ : Edacs Talk Group ID  
  && : Agency No.  
  ## : Fleet No.  
  \$ : SUBFLEET No.

<Example>

TG AA0 01-025[\$r] : AFS format  
TG AA0 000149[\$r] : DECIMAL format

ID in ID memory "BANK A-A10" is "AGENCY=01, FLEET=02, SUBFLEET=5"

>> EDACS PARTIAL ID <<

TG ? @% &&----[\$r]  
Or      TG ? @% &&-\$[\$r]  
  ? : Bank No.(A-E)  
  @% : ID Memory No.  
  @ : ID Scan List (A-E)  
  % : ID Location (1-9,0)  
  &&---- : Edacs Partial Talk Group ID(All Agency)  
  &&-\$ : Edacs Partial Talk Group ID(All Agency-Fleet)  
  && : Agency No.  
  ## : Fleet No.

<Example>

TG AA0 01----[\$r]  
TG AA0 01-02-[\$r]  
② OK[\$r]

=====

**TR** : Set trunking to bank

=====

Controller → Radio

TR & # %%%%%%%% \$\$\$\$ ??? X[¥r]

& : A-E For bank selection.

# : 1,2,3,4,5,6,7 Trunking type.

1:Type1 2:Type2-800 3:Type2-900(not used)

4:Type2-UHF 5:Type2-VHF 6:WIDE BAND EDACS

7:NARROW BAND EDACS(not used) 8:EDACS SCAT

9:LTR

%%%%%%% : Base frequency (Motorola UHF/VHF band only).

\$\$\$\$ : Spacing (Motorola UHF/VHF band only)

The multiple of 5.0 kHz: 0050\*n(1-20)

The multiple of 12.5 kHz: 0125\*n(1-8)

??? (option) : Offset Channel(Motorola UHF/VHF band only)

380~759

X (option) : Base Configuration No.

1 or 2 or 3

Radio → Controller

OK[¥r]

=====

**US** : Confirm/Select U.S state

=====

Controller → Radio

① US[¥r] : Confirm U.S state

② US##[¥r] : Select U.S state

# : U.S state number (01-50 )

01: Alaska	02: Alabama	03: Arkansas
04: Arizona	05: California	06: Colorado
07: Connecticut	08: District of Columbia	09: Delaware
10: Florida	11: Georgia	
12: Iowa	13: Idaho	14: Illinois
15: Indiana	16: Kansas	17: Kentucky
18: Louisiana	19: Massachusetts	20: Maryland
21: Maine	22: Michigan	23: Minnesota
24: Missouri	25: Mississippi	26: Montana
27: North Carolina	28: North Dakota	29: Nebraska
30: New Hampshire	31: New Jersey	32: New Mexico
33: Nevada	34: New York	35: Ohio
36: Oklahoma	37: Oregon	38: Pennsylvania
39: Rhode Island	40: South Carolina	41: South Dakota
42: Tennessee	43: Texas	44: Utah
45: Virginia	46: Vermont	47: Washington
48: Wisconsin	49: West Virginia	50: Wyoming

Radio → Controller

① US##[¥r] : Select U.S state

# : U.S state number (01-50 )

② OK[¥r]

=====

**VR** : Confirm the version of the Product.

=====

Controller → Radio

VR[¥r]

Radio → Controller

VR@ .@@[¥r] @ .@@ : The version of the Product

<Example>

VR1.00[¥r] The version of the Product is 1.00

Note) This value is not the software version.

=====

**WD** : Confirm/Set Warning light Dimmer

=====

Controller → Radio

① WD[¥r] : Confirm warning dimmer setting

② WD@[\$r] : Set warning dimmer

@ : dimmer level

H: high brightness

D: dimmer

F: light off

Note:

if you add the "?" at the end , you can hear the alert sound and you can observe the warning dimmer setting.

Ex) WD? Or WDH?

Radio → Controller

① WD@[\$r] : Set warning dimmer

@ : dimmer level

H: high brightness

D: dimmer

F: light off

② OK[¥r]

< BCT8 OPERATION SPECIFICATION >

=====

WL : Confirm warning light status

=====

Controller → Radio

① WL[¥r] : Confirm warning light status

Radio → Controller

① WLN[¥r] : warning light on

WLF[¥r] : warning light off

=====

WM : Confirm warning mute condition

=====

Controller → Radio

① WM[¥r] : Confirm warning mute condition

Radio → Controller

① WMF[¥r] : warning off mute

WM+[¥r] : warning one moment mute

WMN[¥r] : warning full mute